REV. 01

## **USER MANUAL**

# Motorized core holder XL - Label unwinder -



Please keep the original packaging in case you need to return the unit. If we receive the system in non-original packaging, the warranty may be void. The XL unwinder is used to unwind the labels on roll having fixed 3" internal diameter. The maximum external roll diameter allowed is up to 250 mm (10") while the maximum label width is up to 240 mm (9.45").

An external power supply 100/240VAC - 2.5A at 24V ---- allows an electronic circuit to provide, through the tension arm, the speed and sense of rotation auto adjustment.

### **INSTALLATION**



#### STEP 1

Using the screws, install the outer disc on the unwinder core holder.

### STEP 2

Attach the printer plate to the unwinder. Do not fasten the knobs for the moment.






## STEP 3

Place the printer on the plate using the guide rails.









## STEP 4

Load the media roll and outside disk then tight the knob.

## STEP 5

Push the media under the tension arm and then feed it into the printer (look at the printer's manual how to load media).

## STEP 6

Make sure to align the unwinder with the printer and turn it on.

The system is ready to work.

## SMART SOLUTIONS FOR THE LABELING INDUSTRY Label rewinder, label unwinder, electronic label dispenser and more...





LABEL UNWINDER/REWINDER



SMALL LABEL UNWINDER/REWINDER



LABEL COUNTER



ROLL TO ROLL SYSTEM For label printers



ROLL TO ROLL SYSTEM For Epson printers



ROLL TO ROLL SYSTEM For VipColor VP series



ROLL TO ROLL SYSTEM FOR PRIMERA LX SERIES



MATRIX REMOVER AND SLITTER



LONGITUDINAL LABEL SLITTER



EASY LABEL DISPENSER



ELECTRONIC LABEL DISPENSER



SCORPID SERIES: DIGITAL LABEL FINISHING SYSTEMS



GEMINI: digital die cutter for sheets



VIRGO: Desktop digital finishing system



MDTORIZED CORE HOLDER UNWINDER/REWINDER

- FOR MORE INFO CONTACT YOUR RESELLER -